



# Scorch 10 Mode Adjustable Rapid Fire Operational Guide

---

1. Unpack your Scorch Rapid Fire Controller carefully from the box it came in.
2. Insert a brand new set of AA batteries into the controller.
3. Press the Guide Button to turn on the controller once batteries have been inserted.
4. To turn the Mod on simply hit the sync button one time. Once on you will see the Player 4 LED lit.



5. The Mod can be turned off the same way by hitting the sync button one time.
6. To cycle through the modes you press and hold the LT button then tap the sync button.
7. You will now see it is blinking. If it blinks 5 times and stops it is in mode 5 etc.
8. Setting your SPS – Shots Per Second setting for Adjustable modes. Press and Hold the RT button then tap the sync button. You will see now that Player 3 and Player 4 Leds blinking.



9. Next You will adjust the speed up and down by pressing RT to go up and LT to go down.
10. For Example if the Player 3 Led blinks once and Player 4 blinks 5 times. You are at 15 SPS. The Player 3 Led is worth 10 and Player 4 Led is worth 1.

## ***DETAILED MODE LIST***

**MODE 1** – Fully Adjustable 1-30 sp/s

**MODE 2** – Fully Adjustable 1-30 sp/s

**MODE 3** - 2 Round Burst – Adjustable

**MODE 4** - 3 Round Burst – Adjustable

**MODE 5** - AKIMBO Rapid Fire – Adjustable

**MODE 6** - MIMIC MODE - Dual Rapid Fire on Single Right Trigger – Adjustable

**MODE 7** - AKIMBO Machine Gun Mode – Adjustable

**MODE 8** - Auto Aim Zombie Mode - No Rapid Fire

**MODE 9** - Auto Aim Zombie Mode - With Rapid Fire

**MODE 10** - Quick Scope Delay Adjustable 1 - 30 Milliseconds

If you have any questions contact us via email [support@modjunkiez.com](mailto:support@modjunkiez.com)



Got Modz ?